



Storage
Solutions

HW0523


600mm High

2 Door Wall Cupboard

ASSEMBLY INSTRUCTIONS PAGE 1

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)

PANEL ID:




- ① - LEFT SIDE ④ - BASE ⑦ - SHELVES (X2)
② - RIGHT SIDE ⑤ - BACKBOARD ⑧ - LEFT DOOR
③ - TOP ⑥ - MIDDLE UPRIGHT ⑨ - RIGHT DOOR

PARTS ID:

No	DIAGRAM / DESCRIPTION	Qty
A	DOOR HINGE	4
B	UNITAR SCREW	12
C	WALL PLUG	4
D	SCREW (M3.5 x 16mm)	16
E	SCREW (M3.5 x 30mm)	8
F	SHELF CLIP	8
G	HANGER BRACKET	2
H	WALL BRACKET	2
I	MOONSHAPE DOOR HANDLE	2
	SCREW (M4 x 20mm)	4
J	ALLEN KEY	1
K	UNITAR SCREW CAP	12

WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

WARNING: ALWAYS SECURE this product by installing the **HANGER BRACKET WALL BRACKET** (Step 1) and **ATTACHING** the *Faulkner 2 Door Wall Cupboard* to a **SOLID, FLAT WALL**.

DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.


IMPORTANT: Regularly check that Hanger and Wall Bracket Anchors are securely maintained.

SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).

Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.

ASSEMBLY:


STEP 1



WHITE MATT FINISH

60cm H | 90cm W | 30cm D

STEP 2



600mm High


2 Door Wall Cupboard

ASSEMBLY INSTRUCTIONS

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)

PAGE 2

PANEL ID:



- ① - LEFT SIDE ④ - BASE ⑦ - SHELVES (X2)
② - RIGHT SIDE ⑤ - BACKBOARD ⑧ - LEFT DOOR
③ - TOP ⑥ - MIDDLE UPRIGHT ⑨ - RIGHT DOOR

PARTS ID:

No	DIAGRAM / DESCRIPTION		Qty
A		DOOR HINGE	4
B		UNITAR SCREW	12
C		WALL PLUG	4
D		SCREW (M3.5 x 16mm)	16
E		SCREW (M3.5 x 30mm)	8
F		SHELF CLIP	8
G		HANGER BRACKET	2
H		WALL BRACKET	2
I		MOONSHAPE DOOR HANDLE	2
		SCREW (M4 x 20mm)	4
J		ALLEN KEY	1
K		UNITAR SCREW CAP	12




Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV
on this furniture



STEP



CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

⚠ WARNING: ALWAYS SECURE this product by installing the **HANGER BRACKET WALL BRACKET** (Step 1) and **ATTACHING** the *Faulkner 2 Door Wall Cupboard* to a **SOLID, FLAT WALL**.

! DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.

IMPORTANT: Regularly check that Hanger and Wall Bracket Anchors are securely maintained.


SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).

Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.

ASSEMBLY:

STEP

MOUNTING THE UNIT TO A WALL:



COMPLETE ✓