



HW0748

1800mm High 2 Door Pantry Slim Cupboard


ASSEMBLY INSTRUCTIONS PAGE 1

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)

TWO PERSON
(RECOMMENDED)

PANEL ID:


- A** - KICK BOARD
- B** - BASE
- C** - LEFT DOOR
- D** - RIGHT DOOR
- E** - LEFT SIDE
- F** - RIGHT SIDE
- G** - SHELF / TOP (X4)
- H** - BACKBOARDS (x2)



No	DIAGRAM / DESCRIPTION	Qty
1	UNITAR SCREW	20
2	WOOD DOWELS	24
3	HANDLE	2
4	M4 SCREW (18mm)	4
5	DOOR HINGE	6
6	M3.5 SCREW (16mm)	36
7	NAIL LEG STUD	4
8	BACKBOARD NAILS	40
9	UNITAR SCREW CAP	20
10	ALLEN KEY	1
11	ANTI TIP BRACKET	1
12	WALL PLUG	2
13	M4 SCREW (30mm)	2
14	M3.5 SCREW (16mm)	2

FOR
ANTI TIP
BRACKET

WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV
on this furniture

BLACK-BROWN FINISH

180cm H 60cm W 40cm D

CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

WARNING: ALWAYS SECURE this product by installing the **ANTI-TIP BRACKET** and **SCREWS** (Step 10) and **ATTACHING** the *Faulkner 2 Door Pantry Slim Cupboard* to a **SOLID, FLAT WALL**.

DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.


IMPORTANT: Regularly check that Anti-Tip Bracket and Screws are securely maintained. Stability of tall item may be affected by carpets and uneven floors, or uneven and unstable walls.

SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).


Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.

ASSEMBLY:


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



MADE IN CHINA



HW0748

Storage
Solutions

1800mm High

2 Door Pantry Slim Cupboard


ASSEMBLY INSTRUCTIONS PAGE 2

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)

TWO PERSON
(RECOMMENDED)

PANEL ID:

- A** - KICK BOARD
- B** - BASE
- C** - LEFT DOOR
- D** - RIGHT DOOR
- E** - LEFT SIDE
- F** - RIGHT SIDE
- G** - SHELF / TOP (X4)
- H** - BACKBOARDS (x2)



No	DIAGRAM / DESCRIPTION	Qty
1	UNITAR SCREW	20
2	WOOD DOWELS	24
3	HANDLE	2
4	M4 SCREW (18mm)	4
5	DOOR HINGE	6
6	M3.5 SCREW (16mm)	36
7	NAIL LEG STUD	4
8	BACKBOARD NAILS	40
9	UNITAR SCREW CAP	20
10	ALLEN KEY	1
11	ANTI TIP BRACKET	1
12	WALL PLUG	2
13	M4 SCREW (30mm)	2
14	M3.5 SCREW (16mm)	2

FOR
ANTI TIP
BRACKET

WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV
on this furniture

BLACK-BROWN FINISH

180cm H

60cm W

40cm D

CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

WARNING: ALWAYS SECURE this product by installing the **ANTI-TIP BRACKET** and **SCREWS** (Step 10) and **ATTACHING** the *Faulkner 2 Door Pantry Slim Cupboard* to a **SOLID, FLAT WALL**.

DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.

IMPORTANT: Regularly check that Anti-Tip Bracket and Screws are securely maintained. Stability of tall item may be affected by carpets and uneven floors, or uneven and unstable walls.

SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).


Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.

ASSEMBLY:

STEP


7

TO ADJUST DOOR:




STEP

8




STEP

9



STEP

10



**FIX TO
WALL**

COMPLETE

