



Storage
Solutions


HW0547

1800mm High

3 Door Wardrobe (with 2 Drawers)

ASSEMBLY INSTRUCTIONS PAGE 1

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)



ID	DIAGRAM / DESCRIPTION	Qty
A		62
B		36
C		31
D		5
E		1
F		4
G		7
H		80
I		8
J		3
K		1
L		2
M		2
N		2

WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



WHITE MATT FINISH

180cm H | 120cm W | 58cm D

CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

WARNING: ALWAYS SECURE this product by installing the **ANTI-TIP BRACKET** and **SCREWS** (Step 7) and **ATTACHING** the *Faulkner 3 Door Wardrobe (with 2 Drawers)* to a **SOLID, FLAT WALL**.

DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.


IMPORTANT: Regularly check that Anti-Tip Bracket and Screws are securely maintained. Stability of tall item may be affected by carpets and uneven floors, or uneven and unstable walls.

SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).

Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.


ASSEMBLY:

STEP 1




A x 6
B x 4

STEP 2




A x 24
B x 16

STEP 3



A x 24
B x 8

STEP 4



C x 31



Storage
Solutions


HW0547

1800mm High

3 Door Wardrobe (with 2 Drawers)

ASSEMBLY INSTRUCTIONS PAGE 2

(ASSEMBLE ON A LEVEL, CLEAN SURFACE)



ID	DIAGRAM / DESCRIPTION	Qty
A		62
B		36
C		31
D		5
E		1
F		4
G		7
H		80
I		8
J		3
K		1
L		2
M		2
N		2

WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



WHITE MATT FINISH

180cm H | 120cm W | 58cm D

CARE CAUTION: TO CLEAN PARTICLE BOARD WITH MELAMINE FINISH, PLEASE CLEAN WITH A SOFT, DRY CLOTH. DO NOT USE CHEMICALS OR DETERGENTS AND AVOID WATER AND DIRECT SUNLIGHT.

WARNING: ALWAYS SECURE this product by installing the **ANTI-TIP BRACKET** and **SCREWS** (Step 7) and **ATTACHING** the *Faulkner 3 Door Wardrobe (with 2 Drawers)* to a **SOLID, FLAT WALL**.

DANGER: TOPPLING FURNITURE CAN CAUSE SERIOUS INJURIES AND DEATH.


IMPORTANT: Regularly check that Anti-Tip Bracket and Screws are securely maintained. Stability of tall item may be affected by carpets and uneven floors, or uneven and unstable walls.

SAFETY: Carefully check for any electrical wires or plumbing inside the wall before drilling any holes (If unsure, contact a qualified Tradesman).

Walls are constructed from different materials (i.e: Masonry = Solid Wall, Plasterboard = Hollow Wall) so it is important to use appropriate wall fixings and screws for your wall type. Your local Hardware Store will stock the necessary extra screws, drill bits fixings, and can offer suitable advice if needed.

ASSEMBLY:


STEP 5



(B) x 4

(I) x 4


STEP 6



(A) x 4 (F) x 1

(D) x 1 (H) x 4

STEP 7




(E) x 1

(F) x 2

(H) x 12

STEP 8



(D) x 3

(G) x 7

(H) x 60

(J) x 3

COMPLETE